ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE

Fine Furniture for every stage of life

360121(B1&B2)
Daybed

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

COASTER®
FINE FURNITURE

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME	15 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A	RIGHT SIDE PANEL WITH LABEL "A"	1PC
B	LEFT SIDE PANEL WITH LABEL "B"	1PC
C	LEG WITH LABEL"C"	2PCS
D	LEG WITH LABEL "D"	2PCS
E	ROLL SLAT (13PCS)	1SET

B2 (BOX 2)

F	BACK PANEL	1PC
G	FRONT RAIL	1PC

HARDWARE IDENTIFICATION

Z-B1(BOX 1) - HARDWARE PACK IS LOCATED IN 360121(B1)

|							
1	BOLT (Φ5/16" x 55 mm - RBW)	14PCS	2	LOCK WASHER (Φ5/16" - RBW)	14PCS
3	FLAT WASHER (Φ5/16' - RBW)	14PCS	4	ALLEN WRENCH (4MM - RBW)	1PC
5	THREADED BOLT (Φ5/16" x 90MM - RBW)	4PCS	6	HALF ROUND NUT (Φ5/16'' - RBW)	4PCS
7	HEX NUT (Φ5/16" x 14MM - RBW)	4PCS	8	WRENCH (14MM - RBW)	1PC
9	FLAT HEAD SCREW (Φ4 x 30MM - RBW)	10PCS			

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provided this item.

ITEM:**360121(B1&B2)**
ASSEMBLY INSTRUCTIONS

COASTER®
FINE FURNITURE

STEP 1

F

A

3

2

1

4

* BACK VIEW

STEP 2

F

A

G

5

6

7

8

COASTERFURNITURE.COM

ITEM:**360121(B1&B2)**
ASSEMBLY INSTRUCTIONS
STEP 3

STEP 4

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS

COASTER®
FINE FURNITURE

STEP 5

E   9

STEP 6
COMPLETE

COASTERFURNITURE.COM

ITEM: 360121(B1&B2)

Inner Size : 78.75"W X 39.75"D

35.50"

76.00"

16.00"

46.50"

39.75"

5.50"

36.25"

78.25"

42.25"

85.00"

Note: Dimension tolerance ±5%