

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

910321 SHOE CABINET

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.

2. Please check to see that all hardware and parts are present prior to start of assembly.

3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately. 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME



PARTS IDENTIFICATION



NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



HARDWARE IDENTIFICATION


Z	-						
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	7	PLASTIC FEET Ø15m		4 PCS
2	WOODEN DOWEL Ø8x30mm		34 PCS	8	PIN FOR ADJUSTABLE SHELF Ø4.9 x 15mm SR		4 PCS
3	CAM BOLT Ø7x35.5mm SR		2 PCS	9	GLIDES L = 250mm	CL CR	1 SET
4	CAM LOCK Ø15x12mm SR		2 PCS	10	SCREW FOR HINGE Ø 3x12mm BLK		10 PCS
5	LONG SCREW Ø 4.5x42mm SR	STATE OF THE PARTY	12 PCS	11	BOLT M6x25mm BLK		4 PCS
6	SCREW Ø 4.3x35mm SR		4 PCS	12	STICKER Ø20mm		1 PC

Z9 not included in blister packaging.





NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


























































STEP 13








Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 14




x 1




STEP 15











PAGE 10 OF 12

COASTERFURNITURE.COM






STEP 18 COMPLETE














Note: Dimension tolerance ±5%